

DP 300-S

PIANOFORTE DIGITALE
88 tasti con "hammer action"

Pianoforte digitale dal design moderno con 21 suoni ricchi di Feel. 3 Curve di risposta al tocco possono essere selezionate in funzione dello stile di esecuzione preferito. La tastiera con tasto Hammer Action ed il campionamento Multi Layer lo rendono perfetto per le esercitazioni e le performance artistiche.

DIGITAL PIANO WITH
88"hammer action" keys

Portable digital piano of modern design with 21 sounds full of feeling. You can choose 3 touch response curves according to your preferred style of playing. The Hammer action keyboards and the multilayer sampled make it the perfect instrument for both practice and public performances.



Specifications

Keyboard:	88 Notes Hammer Action
Touch Response:	3 Selectable Curves/Off
Voices:	21 sounds
Polyphony:	64 Notes Max
Layer-Split:	Dual, Split function with volume balance feature
Effects:	3 Reverbs, Chorus
Metronome:	1/4, 2/4, 3/4, 4/4, 6/8, 12/8 with Tempo control
Recording:	2 Tracks Sequencer
Overall Presets:	7 Panel memories
Tuning:	Transpose (+/- 12 semitone)
Demo Songs:	7 demo songs

Midi:	USB Midi/ Midi Out
Pedal:	Sustain
Display:	3 Digit Leds
Headphone:	2 Headphones Socket
Connections:	13,5V Adaptor * L/R Outputs * Midi Out * USB Midi * Pedal sustain * 2 Headphones Socket
Amplification:	2x15 watts
Size:	1390 x 455 x 220 mm
Weight:	19 Kg
Finish:	Black, Anthracite
Power Supply:	ADS 1332 Adaptor /13.5V - 3.2A
Included in supply:	Mains Adaptor, Music stand, Damper pedal
Optional Accessories:	Stand